





















Makin's® Extruder Disc Guide

These are the discs that come with the extruder.

Item# 35055 Ultimate Clay Extruder Discs











				
1	2	3	4	5
				
6	7	8	9	10
				
11	12	13	14	15
				
16	17	18	19	20

Makin's® has provided numbers for their discs. You may want to print this page or mark your discs.











I will use these numbers in future projects to make it easy to know which disc I am using.

These are the extra disc sets you can purchase separately..

Item# 35155 Ultimate Clay Extruder Discs Set A

				
21	22	23	24	25
				
26	27	28	29	30

Item# 35156 Ultimate Clay Extruder Discs Set B

				
31	32	33	34	35
				
36	37	38	39	40